


PERIPHERALS

NETWORK COMMUNICATIONS CARD




Technical Specifications

Standby Current	5.2mA
Cable Requirements	2 core 1.0mm (min) fire rated cable
Comms A - B	RS485 comms, fused \varnothing 20mA
Supply Output	28v, fused \varnothing 500mA
Outputs	6 x programmable switch -ve, max load = 40mA

Order Code

TPCA05	Network Comms Card
--------	--------------------

2 core cable from Comms A to Comms B



- Simple plug in communication card
- Allows networking of up to 8 control panels
- Add up to 8 repeater panels or remote display units to the network
- 2 core cable between cards
- Fully monitored fault tolerant network or legacy radial circuit wiring
- Includes 6 x programmable outputs




+44 (0) 1895 546205

Installation Instructions

The Comms PCB fits into the control panel on top of the main circuit board where the ribbon cable from the display board comms is normally plugged.

To fit the Comms PCB, power down the panel, un-plug the display board ribbon cable from the main circuit board and plug the Comms PCB into the socket instead.


A socket is provided on the top of the Comms PCB to re-connect the display board ribbon cable.




Each panel to be included in the network is defined by setting a switch on the main PCB.

OFF = Stand Alone mode, ON = Network/Repeater mode.

In the case of the Esento Excel this is switch 7 on the 7 way DIL switch




In the case of the Esento Evoke this is switch 3 on the 3 way DIL switch



With this switch in the ON position the panel will automatically recognise & operate the Comms PCB (TPCA05).

Fault Tolerant Loop Wiring



Radial/Legacy Wiring

